



Water Filtration System Operating Instructions

Spigot Installation

- a. Remove spigot from packaging.
- b. Insert spigot into spigot hole from the outside, using washer.
- c. In the interior of the unit screw on wing nut. Hand tighten.
- d. Turn spigot by hand, clockwise, one full rotation (hand tighten only).
- e. Fill unit with water and check for leaks.
- f. If leaking occurs repeat steps d and e.

Filter Installation

- a. Remove filter from packaging.
- b. Wash filter with cold water and cloth or 3m scotch brite pad
- c. Put washer on stem of filter.
- d. Insert filter stem through filter hole with filter upright in the plastic reservoir.
- e. Tighten wing nut on filter stem.
- f. If leaking occurs repeat step e.

Filling Instructions

To retain a constant capacity always add the same amount of water to the filter sleeve that you will be dispensing from the reservoir.

Cleaning Instructions

- a. Remove the filter and clean the filter sleeve and water reservoir (buckets) every two weeks with hot water and soap.
- b. Clean the filter with a soft tooth brush or 3m pad and cold water. (Never use hot water and soap on filter)
- c. Re-install filter and proceed as normal.

Flow Rate

It usually takes several days for the flow rate to increase to 1 gallon per hour. The flow rate will increase as the interior and mixed media becomes completely saturated. If flow rate is slow, clean filter and keep filter sleeve full.

Shelf Life

Once you start using the filter, the activated carbon is only good for 6 to 8 months. The anti-bacterial ceramic wall will work indefinitely. The media inside (such as the activated carbon) will pack over time. The filter needs to be shaken to unpack the media. The shelf life of the unit itself is indefinite. The only question is the carbon. Current figures say the unused carbon should have a shelf life between at least 2 to 3 years, if not much more. The sock has an indefinite shelf life. Replacement during use will depend on filthiness of the water source.